# Lab Report – 1

# **Experiment 1: Testing Not Gate**

Moida Praneeth Jain (2022101093, Group 4, Table 16)


# **Objective**


- Understanding the components and usage of the digital test kit.
- Measuring Voltage between VCC and GND pins.
- Verify working of input pins and output LEDs.
- ➤ Verify 7404 IC (6 NOT gates).

### **Electronic Components Required**


- Power Supply
- > Breadboard
- ➤ LED
- Resistor
- > 7404 IC (Hex Inverter)
- > Switch
- Wires

#### The Reference Circuit





IC:





#### **Procedure**

- Use multimeter to measure voltage between VCC and GND.
- > Connect input switches to LED to verify that they are working.
- > Connect the IC onto the breadboard.
- Connect VCC to the VCC pin of the IC, and connect GND to the GND pin of the IC (using red and black wires respectively).
- ➤ Connect output of any switch to each input switch of the IC, and connect the corresponding output to LED's anode.
- Connect LED's cathode to GND through a resistor.
- > Turn the power supply on.

### **Observation**

- ➤ When the input switch is on, the LED is green.
- ➤ When the output switch is off, the LED is red.





# Conclusion

The NOT Gates are functioning as expected.

TinkerCAD simulation link:

https://www.tinkercad.com/things/26rGVuvhCry-experiment-1/editel?sharecode=xx54mB6UG6GT MbxxYydsvaarcaJMiOoTPbwpHqZvtA

# **Experiment 2: Testing Arduino**

# Moida Praneeth Jain (2022101093, Group 4, Table 16)


# **Objective**


Connect Arduino Uno to breadboard and output "Hello World" in the serial monitor when output of NOT gate is 1 and output nothing when output of NOT gate is 0.

### **Electric Components Required**

- Power Supply
- Breadboard
- > Arduino Uno
- > 7404 IC (Hex Inverter)
- Wires
- > Switch

### **The Reference Circuit**





### Code

```
void setup()
{
    Serial.begin(9600);
}

void loop()
{
    int sensorValue = digitalRead(7);
    if (sensorValue = 1)
        Serial.println("Hello World!");


    delay(100);
}
```

#### **Procedure**

- Connect the IC onto the breadboard.
- Connect VCC to the VCC pin of the IC and GND to the GND pin of the IC (with red and black wires respectively).
- Connect GND to GND of Arduino.
- Connect output of any switch to any input of the IC, and connect the corresponding output to a digital input pin of the Arduino.
- Connect the Arduino to your PC and load the code using Arduino IDE.
- > Turn the power supply on.

#### **Observation**

➤ When the switch is off, "Hello World" is printed on the serial monitor. When the switch is on, nothing is printed.



#### **Conclusion**

The Arduino is working as expected

TinkerCAD simulation link:

https://www.tinkercad.com/things/kyuP9PE0Kcp-experiment-2/editel?sharecode=KyIsZ7Gj3oFpofBOUQ44KDfoJ7GKuoxLFDxtNS9m6wU